

no touch equipment sanitiser station

Sanitising your gym equipment after each use greatly **reduces the chances of members passing on bugs** to fellow gym users. It also helps to preserve the life of the equipment and improves the hygiene of the facility.

We have created a **no touch sanitising station** that is a very **cost effective** and **functional** way of achieving this.

You simply tear off a paper towel, place it under the automatic sanitiser dispenser then wipe down your equipment. We even provide an integrated wastebin for used paper towels.

Fixed sanitiser vs mobile sanitiser

With a mobile sanitising option, like spray bottles, other gym users can be sprayed unintentionally and equipment can be saturated with liquid. The sanitiser station stops any unwanted atomised sanitiser spraying other gym users and reduces the amount of chemical the metal and plastic components of equipment are exposed to.

It is also much more cost effective and controllable than a wet wipe option. Users are more inclined to pull out multiple wipes and wipes tend to leave equipment wet for the next user.

If you want to know more or to arrange a trial call us now on **13 14 40**.

